

※ Please be sure to follow the cautions below when using this product ※


○ This product assumes transportation will be over flat, hard floors.

**Please do not move UFO-Insulators over a floor with varying level.**

The UFO-Insulator will be damaged if used on uneven surfaces.

### UFO-Insulator (For GP), Common points of both G-UFO-S/G-UFO-W

**TOP**




Caster receiver

Stopper Knob

\*After taking the UFO Insulator out of it's box, please raise the stoppers by turning the knob.

Stopper




Internal caster

**BOTTOM**


## Set up instructions

**1**

Lift the legs of the grand piano one by one and place the castors into the castor receivers correctly.



Front side Back side




Please make sure the caster is installed in the caster receiver correctly.

**2**



Stopper's Knob

Turn both knobs (in 2 places) to fix the stopper.  
\*Do not tighten too much.



View of the completed set up

### \*Cautions when using\*

- When you move a grand piano, release the stoppers by using the knobs to raise them to the top position.
- If you loosen the knob too much, the bolt may come off. Please stop loosening the knob when it reaches to the top position.
- Please do not move a grand piano forcefully when the stopper is fixed. The stopper will be damaged or floor will be damaged.