

USER'S MANUAL

● ASSEMBLY METHOD ON THE BACK

■ ASSIST STOOL ASS-V

Release the locked latches on both sides of the assist stool and lift the top plate up. 4 height adjusters are stored inside.

Latch

(LOCK)

(OPEN)

Height adjuster

2.5cm

5cm

7.5cm

※ To adjust the height: There are 5 levels, including the thickness of the wooden plate plus the height adjusters.

1st.. level H: app 2.5cm



▲ ① Pull the 4 non-slip rubber pads out from the corners of the bottom plate.

(Thumbtacks are attached to the backs of the rubber pads.)



▲ ② Attach the non-slip rubber pads to the 4 inside corners of the bottom plate.



▲ Place the bottom plate upside down to complete the 1st level. (Note: the bottom plate has to be placed upside down.)

2nd. level H: app 5cm



▲ You can use the stool in its pre-assembled form.

3rd. level H: app 7.5cm



Fit the top plate onto the adjusters

◀ Insert the height adjusters into the holes and align them so that they are parallel to the outer lines. (picture left)



▲ Rotate the 4 height adjusters by 90 degrees to finish.

4th. level H: app 10cm



◀ Insert the height adjusters into the holes and align them so that they are parallel to the inner lines. (picture left)



▲ After fitting the top plate to the adjusters, rotate the 4 adjusters 90 degrees to secure them.

5th. level H: app 12.5cm



◀ Insert the height adjusters into the holes and align them so that they are parallel to the inner lines. (picture left)



▲ After fitting the top plate to the adjusters, rotate the 4 adjusters 90 degrees to secure them.

● Precautions when using






- Please take care when using the Stool. If some rough surfaces remain around the edges of the wooden plate, they may cause injuries.
- When you need to carry the Stool, you must place the latches in the "lock" positions. Otherwise, it may cause damage to floors or get caught on something.
- Please do not stand on the Stool or use it as a step-ladder. You may risk injury.
- We ask for your kind understanding should there be any slight differences in Stool sizes.

● Assist Stool: Maintenance




- Please always keep the Assist Stool clean using a neutral detergent. Take special care to keep the non-slip rubber pads clean. When they become dirty, the stool can easily slip.
- If the height adjuster's dowels are damaged, please unscrew them and contact the shop you bought the Assist Stool from. We can exchange them for new ones.

■ Assembly Method for the Assist Stool ■

When you assemble the Assist Stool's height adjusters or store them inside the stool, please place the adjusters parallel to the 2 lines carved into the bottom wooden plate.



Procedure (Assembly method)

- 1**  Align the 4 height adjusters so that they are parallel to the carved lines in the bottom plate.
- 2**  Fit the top plate into the concave dowels.
(Check that all 4 height adjusters fit correctly)
- 3**  If you rotate the 4 height adjusters 90 degrees (both clock wise or anti-clockwise are OK), the top plate and the bottom plate will be locked together.
Please make sure that both plates are locked together before using the stool.

Storing Method

- 1** Rotate the 4 adjusters so that they are parallel to the carved lines in the bottom plate. Then remove the top plate by lifting it straight up with both hands.

attention Do not lift the top plate upward on an angle. If the top plate is caught by the dowels, or something else, realign the adjusters so that they are parallel to the carved line.
* If the top plate is caught by dowels, do not forcibly move it. This will damage the dowels.

- 2** Remove the 4 height adjusters from the bottom plate. Then, place them in the storage pockets.
- 3** Combine the bottom and top plates. Then fix the latch knobs in the "Lock" position. The stool would now be safe to carry.

To the guardians

Please instruct children carefully so that they can use the stool in the correct way.